


CABINET PARTS

REFRIGERATOR

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	14	W10142283	Screw	22		Grille
	W10299703	Use & Care Guide	15		Bottom Hinge (FC)		W10257231	White
	W10323418	Service & Wiring Sheet		W10249940	White		W10257232	Black
	W10299711	Energy Label		W10249941	Black		W10257234	Midnight Grey
2	2150304	Front Roller		W10249943	Apollo Grey	23	W10142234	Screw
3	W10297485	Screw	16		Bottom Hinge (RC)	24		Door Closer (FC)
4	12477102	Roller (Rear)		W10257188	White		W10247903	White
5	12477202	Axle, Roller		W10257207	Black		W10257198	Black
6	W10285005	Rivet, Roller		W10257209	Apollo Grey		W10257200	Midnight Grey
7	2223388	Clip, Axle	17		Door Closer (RC)	25	W10001250	Screw
8	W10257186	Bracket, Foot		W10247905	White	26	W10277956	Tube, Filter
9	W10141622	Foot, Brake		W10257195	Black			Inlet
10	W10308750	Screw		W10257197	Apollo Grey	27	W10277957	Tube, Filter
11	W10258560	Valve, Inlet	18	W10141645	Screw			Outlet
12		Hinge, Top (FC)	19	549193	Clamp, Service Cord	28	W10247979	Drain Fitting
	W10247899	White	20	W10257325	Cover, Unit	29	W10280082	Extension Tube
	W10249920	Black	21		Filler, Wrapper	30	12957702	Cover
	W10249922	Apollo Grey		12587703W	White	31	W10158418	Elec. Control-15W
13		Hinge, Top (RC)		12587703B	Black	32	W10235413	Elec. Control
	W10247901	White		12587703AP	Apollo Grey	33		Cabinet (Not A Serviceable Part)
	W10249923	Black						
	W10249925	Apollo Grey						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	W10260403	Cover, Water Filter
3	W10295370	Water Filter
4	W10281161	Air Diffuser Assembly
5	W10260407	Air Diffuser Cover
6	C3680314	Switch
7	W10238085	Rocker Arm
8	W10279030	LED Light Assy
9	W10280385	Thermistor
10	W10260413	Air Filter Housing
11	W10315189	Air Filter
12	W10251520	Air Filter Cover
13	W10238123	Housing, Water Filter
14	W10251510	Cover, Thermistor
15	W10271541	Connector

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

- | | | |
|----|-----------|-------------------------------------|
| 1 | W10290863 | Shelf, Snack Pan |
| 2 | W10309635 | Trim, Handle |
| 3 | W10282883 | Slide, Humidity |
| 4 | W10282880 | Housing, Humidity |
| 5 | W10290871 | Cover, Assy |
| 6 | W10256846 | Snack Pan
(Also Order 8) |
| 7 | W10292504 | Crisper Pan
(Includes 2, 3, & 4) |
| 8 | W10281628 | Trim, Handle |
| 9 | W10256854 | Meat Pan
(Also Order 8) |
| 10 | W10269156 | Shelf Assy |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS


For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	W10260977	Cover Assy
3	W10269160	Shelf, Glass Upper
4	W10280386	Thermistor
5	W10269161	Shelf, Glass Lower
6	W10256858	Pan, Freezer Upper
		Also Order 7
7	W10281629	Trim, Handle
8	2149954	Switch, Rocker Arm Upper
9	W10256861	Pan, Freezer Lower
		Also Order 7
10	2321286	Switch, Rocker Arm Lower
11	2198634	Pin
12	2198635	Spring
13	W10258502	Cover, Emitter
14	W10180607	P.C. Board Emitter
15	W10258510	Cover, Receiver
16	W10296530	P.C. Board Receiver
17	W10323646	Cover, Thermistor
18	W10258520	Flipper
19	W10258540	Slide, Ice Maker Shut Off
20	W10279030	LED Light Assy

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS


For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION
1	W10258516	Ice Bin Assy
2	W10286610	Ice Bin
3	W10178230	Auger
4	2258220	Washer
5	W10138200	Spacer, Step
6	W10178232	Cover, Crusher
7	W10278731	Blade, Rotary A
8	W10138201	Spacer, Step
9	2257020	Blade, Fixed
10	W10278732	Blade, Rotary B
11	W10178238	Block, Blade
12	W10166878	Roll Pin
13	W10278733	Blade, Rotary C
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2220457	Coupling, Upper
17	8281164	Screw
18	3400065	Screw
19	W10258552	Latch, Assy
20	2220458	Coupling, Lower
21	W10258544	Drive Shaft
22	2198607	Spring, Coupling
23	W10293212	Mounting Plate Assembly
24	2198628	Seal
25	W10291905	Gasket
26	2212370	Washer
27	W10312209	Dispenser, Motor
28	W10287594	Cover, Container
100	W10258516	Ice Container (Complete)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item 5)
	W10287400	White
	W10287401	Black
	W10287403	Stainless
	W10287413	Universal Silver
2	W10326952	Door Compartment Assembly
3	W10296816	Screw
4	W10323228	Door Bin, Shallow
5		Door Gasket, Magnetic
	W10247884	Mist Beige
	W10249912	Black
	W10249916	Apollo Grey
6	W10277354	Handle
7	2200087	Thimble-Top
8	W10170540	Stud, Handle
9		Door Closer, Upper Cam
	W10248011	White
	W10257201	Black
	W10257203	Apollo Grey
10	W10296804	Screw
11		Bracket, Door Stop
	W10247909	Chrome
12	2255121	Nameplate
13	W10223573	Set Screw
14	W10323224	Door Bin, Gallon
15	W10326677	Door, Compartment
16		Cover, Door Stop
	W10248013	White
	W10257216	Black
	W10257218	Midnight Grey

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS


For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item 8 And Dispenser Front Parts)
	W10281989	White
	W10290930	Black
	W10290932	Stainless
	W10290941	Universal Silver
2	W10277354	Handle
3	2200087	Thimble-Top
4	W10296804	Screw
5	W10170540	Stud, Handle
6	W10323219	Door Bin
7	W10296816	Screw
8		Door Gasket, Magnetic
	W10247885	Mist Beige
	W10249913	Black
	W10249917	Apollo Grey
9		Door Closer, Upper Cam
	W10248015	White
	W10257204	Black
	W10257206	Apollo Grey
10		Bracket, Door Stop
	W10247907	Chrome
11	W10223573	Set Screw
12		Cover, Door Stop
	W10257220	White
	W10257221	Black
	W10257223	Midnight Grey

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS


For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	W10276255	Grate, Drip Tray
3	W10174827	Bracket, Ice Door
4	W10174808	Chute, Door
5	W10205978	Motor, Ice Door
6	W10174811	Door, Ice
7	W10174809	Support, Ice Door
8	4449745	Screw
9	W10276248	Trim Ring
10	W10294737	Spigot
11	W10254295	Electronic Control Assy
12		Pad, Ice & Water
	W10290361	White
	W10238111	Black
	W10290362	Midnight Grey
13		Tray, Housing
	W10276252	White
	W10276253	Black
	W10276254	Satina
14	W10254300	Front Cover

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


ICEMAKER PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION
1	W10237915	Bracket, Valve
2	628379	Clip, Fuse
3	W10238092	Water Tube
4	489478	Screw
5	W10258564	Filter Valve Asm
6	489276	Screw
7	W10251088	Cover
8	W10141625	Screw (2)
9	W10251082	Mold & Heater Assembly (Also Order 542638
10	W10238126	Fill Tube Assy.
11	W10136605	Ejector
12	W10251078	Ice Striper
13	2194712	Support
14	2315522	Retainer, Thermostat
15	2321258	Thermostat (Also Order 542369 Cement Alumilastic)
16	W10001280	Screw
17	W10251080	Bracket, Mounting
18	W10242384	Harness, Wiring
19	W10122522	Module Assembly
20	W10001220	Screw
21		Motor (Not Serviced, Order #19)
100	W10122580	Complete Ice maker Assembly

AIR FLOW PARTS

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1	W10251462	Fan Scroll
2	W10260421	Retainer, Fan Motor
3	W10260380	Air Duct, Upper
4	W10260440	Bi-Metal, Defrost
5	W10260378	Air Duct Freezer
6	W10001260	Screw
7	W10312014	Fan Motor
8	2169142	Fan Blade
9	W10240370	Gasket, Evaporator Cover
10	2176759	Fan Grommet (2)
11	W10274578	Clip, Mounting
12	W10193316	Harness, Fan Evaporator (Includes #4)
13	W10142292	Screw, Evap Cover
14	W10239739	Cover, Evaporator (Includes #9)
15	842534	Clip, Air Duct

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: 6WSC20C6XW00, 6WSC20C6XB00, 6WSC20C6XY00, 6WSC20C6XD00
(White) (Black) (Stainless) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>			<u>PAINT, BULK (1 qt.)</u>			<u>TORX SCREW WRENCH</u>		
	*350942	Primer, White		799340	Black		1117510	Torx Key
	*350939	Black		799344	White			
	*350930	White		4392900	Biscuit			
	*4392901	Biscuit		8171358	Graphite			
	*8171357	Graphite						
<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>Miscellaneous</u>					
	72017	White		W10300794	Handle Installation Kit			
	72032	Black		212643	Sealer, Gum (4 Feet)			
	4392899	Biscuit		479502	Tape, Vinyl (3/4 x 108")			
	80051	Graphite		505587	Sealer, Mastic (1 Qt.)			
				503695	Cork, Sealer (1/4 Pound)			
				542638	Grease, Silicone (1/2 Oz.)			
				542639	Cement, Alumilastic (1-1/4 Oz.)			
				833938	Kit, Terminal Connector			

***Important:** The spray paint is not to be used where the paint may make contact with the door gaskets.