


For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCN) (Black)



CABINET PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,


For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,

(White) (Stainless Steel) (Bisque) (Stainless-VCN) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts Energy Guide W10184728 English W10184777 Spanish W10190570 Service & Wiring Sheet W10120323 Use & Care Guide 2220407 Modular Icemaker Service Sheet 2308393 Instruction Sheet, Door Removal 2304845 Customer Quick Tips	13	W10138965	Bottom Hinge (RC)	28	2260507	Housing, Water Filter
			14	2304846	White	29	4396841	Water Filter
				2304849	Bisque	30		Cap, Water Filter
				2304848	Black		2260502W	White
				2315169	Apollo Gray		2260502T	Bisque
			15		Grille		2260502B	Black
				2303292W	White		2260502MG	Midnight Grey
				2303292T	Bisque	31	489500	Screw
				2303292B	Black	32	3400113	Screw
				2303292MG	Midnight Grey	33	2303141	Bottom Hinge (FC)
			16	489497	Screw	34	2260519	Block, Housing Support
			17	489464	Screw		2255012	Tube, Filter (Outlet)
			18	2304888	Drain Fitting	35		
2	2174748	Roller, Front (2)	19	2304937	Extension Tube	36	2203770	Hinge Top (FC)
3	3400517	Screw	21	2188739	Cover, Unit	37	2319867	Tube, Filter (Inlet)
4	2203619	Roller, Rear (2)	22		Cabinet (Not A Serviceable Part)	38		Button, Water Filter
5	489427	Screw					2260503W	White
6	2155013	Clip, Grille	23		Hinge Cover		2260503T	Bisque
7	489478	Screw		2203408W	White		2260503B	Black
8	2156056	Shim		2203408T	Bisque		2260503MG	Midnight Grey
9	2203771	Hinge Top (RC)		2203408B	Black	39	2223751	Door Closer, FC
10	2203575	Pin		2203408AP	Apollo Gray	40	2305373	Clamp, Cord
11	8281227	Screw	24	549193	Clamp, Service Cord	41	2204158	Rod Assembly
12		Hinge Cover				42	2204165	Screw
	2203407W	White	25	489084	Screw	43	2203576	Clip
	2203407T	Bisque	26	2155311	Door Closer, RC			
	2203407B	Black	27	489483	Screw			
	2203407AP	Apollo Gray						

REFRIGERATOR LINER PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	W10175967	Escutcheon, Meat Pan Control
3	2182757	Slide, Meat Pan Control
4	2257741	Louver
5	2188819	Thermister (RC)
6	2319866	Shelf Ladder
7	489478	Screw
8	W10004810	Screw
9	2261602	Door Control Asm
10	W10128726	Air Diffuser Assembly
11	W10128736	Cover, Air Diffuser
12	W10171321	Cover, Conduit
13	2162085	Socket
14	2304920	Reservoir
15	W10194422	Light Bulb
16	2317782	Light Lens
17	488280	Screw
18	2256035	Bracket, Dual Crisper
19	2311637	Wire Harness, Dual Crisper

REFRIGERATOR SHELF PARTS


For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,

For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,

(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)




Illus. No.	Part No.	DESCRIPTION
1	2195975	Frame Assembly (2)
2	2188667	Snack Bin Asm (Includes #19)
3	2209698	Cover, Crisper
4	2179404	Rack, Wine & Egg (For Models: 106.57792703, 106.57793703, 106.57794703, 106.57796703, and 106.57799703 Only)
5	2179259	Glass, Meat Cover
6	2196483	Stud Assembly
7	2311726	Cover, Meat Pan
8	2216624	Egg Bin
9	2313311	Crisper Pan Asm (Includes #10, 11 and 16)
10	2179342	Slide, Humidity Control
11	2179343	Body, Humidity Control
12	W10141750	Shelf Pan Assembly
13	2313312	Meat Pan Assembly (Includes #18)
14	8281158	Screw
15	2216108	Glass, Crisper Cover
16	2313313	Handle Trim
17	2179350	Deflector
18	2313314	Handle Trim
19	2179243	Handle Trim
20	W10141748	Shelf Assembly, Glass Sliding (2)
21	3400894	Screw
22	2196485	Stud Assembly



FREEZER LINER PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)



FREEZER LINER PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)


Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2211746K	Shelf, Slide Out
3	2301190	Basket, Tall
4	3400893	Screw
5	2195905K	Trim, Basket
6		Shelf Track
	2301289	Right Side
	2301290	Left Side
7	2205837K	Shelf (2)
8	2301191	Basket, Sloped
9	W10004810	Screw (8)
10	842534	Clip, Air Duct (2)
11		Shelf Track (3)
	2301293	Right Side
	2301294	Left Side
12	2198587	Cover, Emitter
13	2198697	Gasket
14	2198635	Spring
15	2198634	Pin
16	1115373	Switch, Rocker Arm
17	W10193840	P.C. Board Emitter
18	2255720	Cover, Ice Maker
19	2212321	Slide, Ice Maker Mounting
20	489478	Screw
21	489214	Screw
22	2162085	Light Socket
23	W10194422	Light Bulb
24	8281185	Screw
25	2198633	Flipper
26	W10173569	Cover, Receiver
27	2315398	Slide, Ice Maker Shut Off
28	W10193666	P.C. Board, Receiver
29	2198643	Lens
30	2198589	Light Shield
31	2212340	Light Lens
32	2198641	Bracket, Ice Maker Cover
33	2155597	Socket, Light
34		Ladder
	2198609	Left Side
	2198610	Right Side
35	2303234	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,

For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,

(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)



MOTOR AND ICE CONTAINER PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,


For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,

(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)

Illus. No.	Part No.	DESCRIPTION
1	W10139383	Ice Bin
2	W10140687	Crusher Bin
3	W10140653	Auger
4	2258220	Washer, Auger
5	1119007	Spacer, Flat (4)
6	W10139321	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2317239	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2220457	Coupling
17	8281164	Screw
18	3400065	Screw
19	2305382	Rubber Boot
20	W10140683	Latch, Bin
21	2198608	Spring, Latch
22	2187813	Wire Assembly, IDI Motor
23	2317243	Wiper
24	2212369	Holder
25	2220458	Coupling, Bottom
26	2198628	Seal
27	2212370	Washer
29	2198607	Spring
30	2305243	Drive Shaft
31	2317250	Divider, Chamber
32	2252130	Dispenser, Motor
33	2305208	Bracket, Motor
35	8281163	Screw
36	2212365	Sleeve, Coupling
100	W10140650	Ice Container (Complete)

REFRIGERATOR DOOR PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)




REFRIGERATOR DOOR PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item #6)
	2303522W	White
	2303522T	Bisque
	2303522B	Black
	2303522SAP	Stainless Steel
	2303522LAP	Stainless VCM
2	2305514	Top Door, Chiller
3	2188865K	Door Bin
4	3400012	Screw
5	2219698	Stud, Handle
6		Door Gasket, Magnetic
	2221302	Mist Beige
	2221313	Black
7	2318736	Trivet
8		Handle (Includes #13)
	2254603W	White
	2254603T	Bisque
	2254603B	Black
	2254604S	Stainless
9	488208	Screw
10	2182178	Door Closer, Upper Cam
11	489420	Screw
12		Bracket, Door Stop
	2200082	Chrome
	2200082B	Black
13		Screw
	W10010140	Chrome
	W10010150	Black
14	2305515	Bottom Door, Chiller
15	W10121601	Complete Assembly, Fruit Bin
16	2255472	Frame, Door Chiller
19	2313390	Bin Assembly, Tilt-Out
20	2323099	Nameplate-KEN
21	2319742	Floor Assembly, Chiller
22	2303287	Divider, Bin (2)
23	W10127505	Basket, Berry
24	2313227	Strainer, Bin

FREEZER DOOR PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)




FREEZER DOOR PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes #8 And Dispenser Front Parts)
	W10149676	White
	W10149677	Bisque
	W10149678	Black
	W10149682	Stainless Steel
	W10149681	Stainless VCM
2		Handle (Includes #15)
	2254603W	White
	2254603T	Bisque
	2254603B	Black
	2254604S	Stainless
3	2219698	Stud, Handle
4	488208	Screw
5		Door Gasket, Magnetic
	2221303	Mist Beige
	2221314	Black
6	2171157K	Trivet
8	2223752	Door Closer, Upper Cam
9	489420	Screw
10		Bracket, Door Stop
	2303113	Chrome
	2303113B	Black
11		Screw
	W10010140	Chrome
	W10010150	Black
12	2304309	Basket, Tilt-Out (2)
13	3400012	Screw
14	2223334	Trivet, Tilt-Out (2)
15	2310084	Wire Assy, FC Door

DISPENSER FRONT PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)



DISPENSER FRONT PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,


For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,

(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)	13		Pad, Water	18	2305447	Clip, Wiring
2	W10178851	Wire Assembly, User Interface		2305381WG	For White Model	19		Overlay, Front Cover (Not Available Order #23)
3	2305202	Bracket, Motor		2305381DW	For Bisque Model	20	2303841	LED Assembly
4	2305242	Connector, Door Bracket		2305381RG	For Black, Stainless and Stainless VCM Models	21		Front Cover, Housing (Not Available, Order #23)
5	2305262	Motor, Ice Door	14		Front Assembly, Drip Tray	22		Tray, Housing
6	2305258	Door, Ice		2305356W	White		2305324W	White
7	2305204	Support, Ice Door		2305356T	Bisque		2305324T	Bisque
8	4449745	Screw (2)		2305356B	Black		2305324B	Black
9		Grille, Slide		2305356US	Universal Silver		2305324AP	Apollo Gray
	2305323W	White	15	2305219	Cover, PC Board	23		Front Cover Assembly (Includes Items 13, 16, 17, 19, 20 & 21)
	2305323T	Bisque	16	2321705	Cover Assembly (User Interface)		W10135575	White
	2305323B	Black					W10135576	Bisque
	2305323AP	Apollo Gray	17		Pad, Ice		W10135577	Black
10	W10187441	Spigot		2305321WG	For White Model		W10135578	Universal Silver
11		Separator Assembly		2305321DW	For Bisque Model			
	2305462W	White		2305321RG	For Black, Stainless and Stainless VCM Models			
	2305462T	Bisque						
	2305462B	Black						
	2305462AP	Apollo Gray						
12	2303843	Electronic Control (Core)						

AIR FLOW PARTS


For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2155590	Retainer
3	2313359	Air Duct, Upper
4	2198580	Air Duct Freezer
5	2321799	Bi-metal, Defrost
6	2315549	Fan Motor
7	2169142	Fan Blade
8	2188819	Thermister (FC)
9	2176759	Fan Grommet (2)
10	2304241	Gasket, Evaporator Cover (2)
11	W10129815	Harness, Fan Evaporator (Includes #5)
12	2155789	Gasket, Fan Scroll
13	2172840	Strap
14	2203876	Gasket
15	2206314	Cover, Evaporator (Includes #10)
16	8281159	Screw (6)
17	489478	Screw
18	2203595	Support, R.S.
19	2203596	Support, L.S.

CONTROL PARTS


For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)



Illus. No.	Part No.	DESCRIPTION
1	W10134301	Control Box
2	2219875	Switch, Light
3	2321723	Electronic Control
4	8281244	Screw (4)
5	940014	Hole Plug
6	2304107	Insert, Control Box
7	2162085	Light Socket
8	W10194422	Light Bulb
9	W10167500	Control Box Harness
10	W10204958	Overlay, Control Box

UNIT PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)



UNIT PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,


For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,

(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2169104	Insulation-Sound	23		Drier	40	489478	Screw
2	2225834	Fan, Blade		W10177049	Production	41	W10169512	Clip, Wire & Tube
3	W10121484	Condenser Assembly		2317845	Service	63	2320323	Union
4	489464	Screw	24	W10120460	Compressor	Following Parts Not Illustrated and Optional Parts Not Included		
5	2216914	Clip, Condenser			(Includes Items			
6	2217194	Heat Shield			13, 23, & 30)			
		And Drain Pan			(Also Order			
7	2205765	Tube, Suction			876765 Tube Kit)			
8	1115374	Clip, Wiring	25	2304904	Unit Mounting	978025	Valve, Access	
9	8533993	Screw			Frame	978026	Valve, Access	
10	W10133000	Cover	26	2181929	Bracket, Fan Motor		(5/16")	
11	2223314	Clip, Retaining	27	2323198	Heater, Defrost	978027	Valve, Access	
12	2304885	Start-Device,	28	2304287	Clip, Heater		(3/8")	
		Combination	29	489373	Screw	978028	Valve, Access	
		(Start Relay and	30		Grommet (4)		(1/2")	
		Overload)		1100826	Production	978029	Valve, Access	
13	2264017	Capacitor		4387558	Service		(5/8")	
14	W10172546	Electronic Control	31	489340	Screw	978030	Valve, Access	
15	2255623	Control Box	32	2196202	Air Baffle		(3/4")	
16	2304899	Unit Cover, Bottom	33	2155547	Clip, Heat	876764	Valve, Access	
17	489396	Clip	34	2305374	Unit Mounting		(3/16")	
18	2188823	Evaporator			Rail	REFRIGERANT CHARGE		
19	2161324	Clip	35	8281232	Screw			
20	2188875	Motor, Fan	36	2260517	Guard, Fan		5.0 oz.	
21	1105523	Tray, Evaporator	37	2161302	Sleeve		(R-134A)	
22	2310061	Harness, Unit	38	2172840	Wire Tie			
			39	489427	Screw			

ICEMAKER PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)



ICEMAKER PARTS

For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,

For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,

(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2303216	Fitting and Water Tube
3	2305380	Union, Tube
4	2305388	Tube, Water
5	628379	Clip, Fuse
6	W10159839	Smart Valve
7	2208136	Clip, Water Tube
8	2174358	Cover
9	488649	Screw
10	W10122527	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
11	2304969	Cup-Water Fill
12	627843	Ejector
13	2198598	Ice Stripper
14	2194712	Support
15	2315522	Retainer, Thermostat
16	627985	Thermostat (Also Order 542369 Cement Alumilastic)
17	8533917	Screw
18	2303583	Bracket, Ice Maker Mounting
19	489276	Screw
20	2187467	Harness, Wiring
21	626691	Module Assembly (Includes Items 22 & 23)
22		Motor
23	489136	Screw
100	W10190960	Icemaker Assembly

**For Models: 106.57782704, 106.57783704, 106.57784704, 106.57786704, 106.57789704,
For Models: 106.57792704, 106.57793704, 106.57794704, 106.57796704, 106.57799704,
(White) (Stainless Steel) (Bisque) (Stainless-VCM) (Black)**